

360 DEGREE FLYWHEEL TAPE

To print this degree tape from Acrobat:

- 1. Select "File" from the menu
- 2. Select "Print" from the drop down menu
- 3. Make sure the "Page Scaling" option is set to "none"
- 4. Insert legal size paper (8-¹/₂x14) in the printer and click "OK" to print
- 5. Check the length of the line below to verify the scale

To use:

- 1. Cut the degree tape out of the paper along the dashed lines
- 2. Rotate flywheel to TDC
- 3. Make index marks on both the flywheel and some convenient reference point on the engine case
- 4. Align "0" on the degree tape with the index mark on the flywheel
- 5. Tape the degree tape to the flywheel
- 6. If properly applied, the two "180" marks on the tape should come together

